

RAYFLEX RUBBER CHILLFLEX BLIND

Installation Guide And Fitting Instructions

Fridge and Freezer applications worldwide benefit from the installation of PVC Strip Curtains, Rayflex's Chill-flex system is designed to keep commercial fridges and freezer and the produce within them within an acceptable temperature tolerance.

Reducing your energy bills significantly, ensuring products are kept at their best without hindering access or visibility for the customer.

KEY TIPS

1. Before fitting these curtains, if you are unsure about any aspect of the installation process please contact us for further advice;
2. Before removing the adhesive backing, please ensure you have marked where they are to be fitted to the fridge / freezer;
3. Steps 4 and 8 are critical, please make sure the longest lip is fitted uppermost;

FITTING INSTRUCTIONS

<p>1 Unroll each curtain and lay it flat for 30 minutes to allow the PVC strips to straighten out. Sort the C-sections into identical pairs and make sure they fit the cabinet widths.</p>	<p>2 The surface to which the C-sections are to be fitted must be clean and dry. Please use the surface cleaner provided, wiping it in one direction only and then allow five minutes for the liquid to evaporate. Do not use polish.</p>	<p>3 Take a C-section and peel off about 2" (5cms) of the release strip from each end of the self-adhesive tape.</p>
<p>4 Make sure the longer lip of the C-section is uppermost and line up its lower edge with the bottom of the fascia, ensuring it is horizontal so that the curtain hangs smoothly. Press each end lightly so that, if necessary, you can make any adjustments. When you are satisfied with its position, pull the release strip away completely and press the C-section firmly into place. Leave for 10 minutes to ensure strong adhesion before moving on to instruction 5.</p>	<p>5 Slot the curtain into the C-section and let it hang down over the sill.</p>	<p>6 Mark on the cabinet, with a pencil, the position of the lower edge of the bottom rail.</p>
<p>7 Take a matching C-section, again with its longer lip uppermost, and fix it 1" (2.5cms) above the mark.</p>	<p>8 Slot the bottom rail into the C-section and add the sidestrips if applicable.</p>	<p>9 Add the sidestrips to the sides of the curtain.</p>

FOR ANY QUESTIONS OR COMMENTS, PLEASE CONTACT OUR EXPERIENCED TEAM.